


RADIOMARELLI

mod. RD 218-224



TONE	B	B	B	E	S
VOICE					
BASS					
ALTI					
MUSICA					
JAZZ					

	B	B	B	B	E	S
FM						
OC						
OL						
OM						
FONO						
SPENTO						